Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and can be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Item	Function	Default setting	Customized setting
Smart access system with push-button start	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
Wireless remote control	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	On	Off
	Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	60 seconds	30 seconds
			120 seconds
	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
	Door lock buzzer	On	Off
	Trunk unlocking function	On	Off
	Trunk unlocking operation	Press and hold	Press twice
			One short press
	Panic function	On	Off

Item	Function	Default setting	Customized setting
Door lock	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Speed-detecting automatic door lock function	Off	On
	Opening driver's door unlocks all doors	Off	On
	Shifting to P unlocks all doors.	On	Off
	Shifting to a position other than P locks all doors.	On	Off
Steering wheel	Auto tilt-away function	On	Off
Power windows	Linked door lock operation	On	Off
	Linked door key operation	Open and close	Open only Close only
	Wireless remote control linked operation	On	Off
Moon roof	Linked door lock operation	On	Off
	Linked door key operation	Open and close	Open only Close only
	Linked operation of components when door key is used	Slide only	Tilt only
	Wireless remote control linked operation	On	Off
	Linked operation of components when wireless remote control used	Slide only	Tilt only
Automatic light control system	Light sensor sensitivity	Level 3	Level 1 to 5
	Time elapsed before headlights automatically turn off after doors are closed	30 seconds	0 seconds 60 seconds 90 seconds
Lights	Daytime running light system (U.S.A. only)	On	Off

<table>
<tr><th>Item</th><th>Function</th><th>Default setting</th><th>Customized setting</th></tr>
<tr><td rowspan="3">Windshield wipers and washer</td><td>Switching operation when the vehicle is stationary</td><td>On</td><td>Off</td></tr>
<tr><td>Drip prevention function</td><td>On</td><td>Off</td></tr>
<tr><td>Time elapsed before the drip prevention function operates</td><td>Variable depending on the vehicle speed</td><td>3 seconds</td></tr>
<tr><td rowspan="3">Intuitive parking assist</td><td>Back sensor operation display and buzzer</td><td>On</td><td>Off</td></tr>
<tr><td>Buzzer volume</td><td>Level 3</td><td>Level 1 to 5</td></tr>
<tr><td>Distance to which a sensor detects</td><td>4.9 ft. (150 cm)</td><td>2.0 ft. (60 cm)</td></tr>
<tr><td rowspan="7">Illumination</td><td rowspan="2">Time elapsed before lights turn off</td><td rowspan="2">15 seconds</td><td>7.5 seconds</td></tr>
<tr><td>30 seconds</td></tr>
<tr><td>Operation when the doors are unlocked</td><td>On</td><td>Off</td></tr>
<tr><td>Operation after the “ENGINE START STOP” switch turned OFF</td><td>On</td><td>Off</td></tr>
<tr><td>Front foot well lighting</td><td>On</td><td>Off</td></tr>
<tr><td>Shift lever lighting</td><td>On</td><td>Off</td></tr>
<tr><td>Outer foot light</td><td>On</td><td>Off</td></tr>
<tr><td>Seat belt reminder</td><td>Vehicle speed linked seat belt reminder buzzer</td><td>On</td><td>Off</td></tr>
</table>

Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

- **U.S. OWNERS**
  - In the U.S. mainland or Canada:
    Lexus Roadside Assistance
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
  - In Hawaii:
    Servco Automotive Roadside Assistance/Customer Services
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
- **CANADIAN OWNERS**
  - In Canada or the U.S. mainland:
    Lexus Roadside Assistance/Customer Service
    1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our **websites** for further information.

- The U.S. mainland: **www.lexus.com**
- Hawaii: **www.servcolexus.com**
- Canada: **www.lexus.ca**